

Headphone
Volume

Power LED

Headphone
Jacks Both
1/8" and 1/4"

Power
On/Off



Input from Boom Mic or any
other Mic.

Output to XLR Input
of Recorder

Battery compartment on back.
Uses 2 AAA batteries.
Batteries not included.